



X45U Repair Guide

X45U Schematic R1.0




POWER FLOW




POWER ON SEQUENCE

AC mode: When AC in, +3VA and +Vsus power on
BAT Mode: +3VA power on after press power button



Voltage & Signal Measure Point TOP



Voltage & Signal Measure Point Bottom

