



# N551ZU Repair Guide

Jan/8/2015  
changcai\_zhou  
GTSD

## N551 Block Diagram




## POWER FLOW



[illegible]

AC BAT SYS


# AC\_IN POWER ON SEQUENCE



# DC\_IN POWER ON SEQUENCE


DC-IN Mode

N551ZU Power Sequence  
(DC mode)





## Signal Measure Point-Bottom





## Signal Measure Point-Top

