


P8H61-I LX Repair Guide


02/23/2012

Leilei52_Chen


CSC-GRMA




POWER FLOW



POWER ON SEQUENCE




4 J L




Voltage Measure Point

Pink number is the GND diode resistance (without any part on MB)multimeter type DH-1240

multi meter "VΩ mA" port touch here



Signal Measure Point(T)



Signal Measure Point(B)

