



## CROSSHAIR V FORMULA


Revision: 2011.01.6  
1.00




# POWER FLOW



# POWER ON SEQUENCE



# Frequency Flow






## Voltage Measure Point


Pink number is the GND diode resistance (without any part on MB) multimeter type DH-1240

multi meter "VΩmA" port touch here





# Signal Measure Point





# Signal Measure Point

